

Infosheet

Controlling projectors or displays in the rooms C426, D404, D435, E405, G203, G302, H244, P601, V1002

As far as a screen is available it will go down automatically at start-up and will raise automatically when turning off the system.

system off (projector/display and audio)		system on (projector/display and audio)
input-choice of the projector to „VGA“		input-choice of the projector to „HDMI“
Turn up the volume of the audio-input		Turn down the volume of the audio-input
As far as a screen is available it can be lowered manually for overhead-presentations		As far as a screen is available it can be raised manually after overhead-presentations

for technical problems

Mo.-Thu.: 7:00h - 15:30h und Fr.: 7:00h - 14:30h

Fabian Jetschmanegg

88-5098

or

8044 (internal/radio)

Jan Lenz

88-4020

or

8002 (internal/radio)

Sa./So. building service

8076 (internal/radio)

ambulance/fire

88-2222

Universität
Konstanz




To adjust the screen resolution in different Windows versions



Windows XP:
Desktop => rightclick => properties => Tab „Settings“ => Adjust the resolution to 1024x768




Windows Vista:
Desktop => rightclick => adjust/customize => Adjust the resolution to 1024x768



Windows 7/8:
Desktop => rightclick => Screen resolution => Adjust the resolution to 1024x768

To adjust the screen resolution in Apple MacOS X



To adjust the screen resolution in MacOS X you have to follow the following steps:
 AppleMenu (top left) => SystemSettings => Monitors
 Afterwards go to the tab „Monitor“ and chose 1024x768 / 75 Hz.
 Please activate „Sync Monitors“ in the tab „arrange“.
 By use of the Button „collect windows“ the two windows will be collected for the different displays in the main window.



If „show monitors in menu bar“ activated you can adjust the resolution and the sync behaviour directly over the menu bar.